

TEXAM

WALL MASTERS

www.texam-wallmasters.com

info@texamhome.com

T: +39 035 460449

Via Milano 10, 24030 Presezzo (BG) Italy

Collection

LOOM

HANGING INSTRUCTIONS

WARNING: DO NOT INSTALL THE PRODUCT BEFORE YOU HAVE READ THE INSTRUCTIONS CAREFULLY.

Thank you for choosing Texam Wall Masters Italian handcrafted creations. For an optimal and professional result we recommend contacting a professional installer.

GENERAL INFORMATION:

Before installing the product, ensure that the color, design, quantity, and quality match the ordered item. Also, confirm that you have received the same production batch. In the event of such defects, the purchased material must be returned entirely and in its original packaging; no complaints about cut or glued products will be accepted. Any color and texture variations are due to the artisanal manufacturing technique. We recommend removing the product from its packaging 24 hours before installation and letting it sit in the environment to be wallpapered to ensure temperature and humidity conformity, preventing the product from contracting during installation.

WALLCOVERING INSTALLATION

1. GLUE:

We recommend using a high-quality, high-adhesion transparent PVA adhesive for wallcoverings. Apply the adhesive directly to the wall, avoiding excessive use; do not dilute it with solvents or any other liquid. Important: follow the adhesive manufacturer's instructions. Texam disclaims any responsibility for adhesive selection.

2. WALL PREPARATION:

Before commencing product installation, ensure the wall is: flat, clean, thoroughly dry, compact, slightly absorbent, uniform in color, solid, free from grease, dust, plaster, oil, or pencil marks. Also, remove any previous wallcoverings and level or eliminate protruding points. Light-colored wallcoverings require a light and uniform wall; if the wall color significantly differs from the wallcovering color, apply a Primer on the wall, matching the covering color. Treat excessively absorbent and dusty walls (like those made of plaster).

3. INSTALLATION:

Always check the installation symbol - standard or reverse hanging - on the roll's label.

Position the adjacent sheets following the numerical order on the roll, starting from the lowest number and progressing to the highest. It's recommended to install and finish one sheet at a time. After installing 3 sheets, carefully inspect the result. In case of defects, immediately stop work and contact the manufacturer. Handle the material with care, avoiding folds or damage. Apply the adhesive evenly, using a brush for areas near the ceiling, skirting boards, and corners. Use a microfiber roller for the remaining areas. Level the joints with a rubber roller, avoiding excessive pressure that might cause adhesive leakage at the seams on the surface. If this happens, immediately clean with a damp sponge in warm water or a clean, lint-free white cloth. Use only water without detergents, frequently changing the water used to maintain cleanliness and prevent halo formation, taking care not to rub the backing too hard. Note that TEXAM disclaims any responsibility for product damage resulting from an inadequate cleaning process.

Gently run a plastic spatula over the backing to remove any air bubbles. Trim excess material using a spatula as a guide and a sharp blade.

4. CLEANING:

ATTENTION: For wallcovering cleaning, use the vacuum cleaner's soft brush or gently scrub with a clean, dry sponge, if necessary. Avoid vigorous rubbing and do not use bleach-based detergents.

SPECIAL WARNINGS:

It is recommended for this product to change the cutting blade often. It is possible to find a slight color difference with the original sample (due to the craftsmanship of the production). For this product it is essential to use a high-strength glue for heavy wallcovering and to use the spatula in the most delicate way possible. It is also advisable to leave the sheets stretch out for a few minutes before placing them on the wall, so that the material "relaxes" and is easier to hang.

ATTENTION:

Any complaints must be made within 10 days of receiving the material, accompanied by a copy of the invoice, photos of the identified defect, and the return of the material. Claims beyond installing 3 sheets will not be accepted. If the claim is justified, Texam's liability is limited to the free replacement of the material. Labor costs will not be refunded.

For any further information please visit our site www.texam-wallmasters.com