

# TEXAM

WALL MASTERS

TEXAM

T+39 035 460449 F+39 035 461452 |  
info@texamhome.com | Via Milano 10,  
24030 Presezzo (BG) Italy  
| V A T I T O 0 9 1 6 3 7 0 1 6 6

www.texamhome.com

Collection

## REALE

### HANGING INSTRUCTIONS

#### WARNING: DO NOT INSTALL THE PRODUCT BEFORE CAREFULLY READING THE INSTRUCTIONS

Thank you for choosing Texam Wall Masters' Italian artisan creations. For optimal and professional results, we recommend consulting a professional installer.

#### GENERAL INFORMATION:

Before installing the product, verify that the color, design, quantity, and quality match the ordered item; also ensure that you have received the same production batch. If defects of this nature are found, the purchased material must be returned in its entirety and in the original packaging; we will not accept any claims for cut or glued products. Any variations in color and texture are due to the artisanal manufacturing technique. We recommend removing the product from the packaging 24 hours before installation and leaving it in the environment to be wallpapered so that the temperature and humidity are consistent, thus preventing the product from shrinking during installation.

#### INSTALLATION:

##### 1. ADHESIVE:

We recommend using a high-quality, high-strength white PVA adhesive for wallcovering. The adhesive must be applied directly to the wall and not excessively; it should not be diluted with solvents or any other liquid. Important: follow the manufacturer's instructions for the adhesive. Texam disclaims any responsibility for the choice of adhesive.

##### 2. WALL PREPARATION:

Before starting to install your product, ensure that the wall is: flat, clean, thoroughly dry, compact, slightly absorbent, uniform in color, solid, free of grease, dust, plaster, oil, or pencil marks. Also, make sure to remove any previous wall coverings and smooth out or eliminate protruding points. Any light-colored wall covering requires a light and uniform wall; if the wall color significantly differs from the wall covering color, it is advisable to apply a primer to the wall that matches the color of the covering. It is also recommended to treat walls that are too absorbent and dusty (such as plaster walls).

##### 3. INSTALLATION:

Place the panels side by side following the roll's numerical sequence, starting from the lowest number and working your way up to the highest. Install and finish one panel at a time. After installing 3 panels, check the result: if there are any defects, stop work immediately and contact the manufacturer. Handle the material carefully to avoid bending or damaging it. Apply the adhesive evenly; use the brush near the ceiling, skirting board, corners, and for all other parts, use a microfiber roller. Smooth out the joints with a rubber roller, being careful not to squeeze out the adhesive; if this happens, promptly clean with a clean sponge lightly dampened with cold water and specific velvet cleaner, being careful not to rub excessively and against the grain of the backing (TEXAM cannot be held responsible for damage to the product during the cleaning process). Gently use a wide rubber roller on the backing to remove any air bubbles that may have formed. Under no circumstances should a plastic spatula be used on the backing to flatten or remove air bubbles, as it would be irreparably damaged; however, a soft-bristled brush can be used. Cut off excess material using a spatula as a guide and a sharp blade.

#### SPECIFIC INSTRUCTIONS:

Handle the backing with care, avoiding bending it. It is also recommended to change the cutting blade frequently. You may encounter the following characteristics: differences in color from the original sample (due to the artisanal dyeing technique of the fabric), visible seams (due to fabric cutting). For this product, it is essential to use high-strength adhesive for heavy wallpapers. Do not reverse hang. Cleaning the wallpaper can be done carefully using the soft brush attachment of a vacuum cleaner or by gently dabbing with a clean, dry sponge if necessary. It is important to avoid applying excessive pressure during cleaning. Bleach cleaning agents are not recommended. The roll should always be suspended from the ground as it could become irreversibly marked.

#### WARNING:

Any claims must be made within 10 days of receiving the material, along with a copy of the invoice, photographs of the defect, and the return of the material itself. Claims will not be accepted after the installation of 3 panels. If the claim is justified, Texam's liability is limited to the free replacement of the material. Labor costs will not be reimbursed.

For further information, visit our website [texamhome.com](http://texamhome.com).

REVERSE HANG ONLY IF SPECIFIED ON THE INDIVIDUAL ROLL'S LABEL



**Light Resistance**  
Good lightfastness



**How to remove**  
Strippable



**Breathable**



**Fire resistant**  
B-s1 d0



**Washability**  
Washable