



ONLINE  
Collection

TEXAM  
WALL MASTERS

**WARNING: DO NOT INSTALL THE PRODUCT BEFORE YOU HAVE READ THE INSTRUCTIONS CAREFULLY**

Thank you for choosing Texam Wall Masters Italian handcrafted creations. For an optimal and professional result we recommend contacting a professional installer.

**GENERAL INFORMATION:**

Before installing the product, check that the color, design, quantity and quality are those ordered; also make sure that you have received the same production batch. Should there be errors of this kind, we ask you to return the complete order to us in the original packaging; we will not accept any claims of the cut or glued product. Any variations in color and texture depend on the artisan manufacturing technique. We recommend removing the product from the packaging 24 hours before installation and leaving it in the room where it will be hanged so that it adapts to the temperature and humidity of the room, to prevent the product from shrinking.

**WALL COVERING INSTALLATION**

**1. GLUE:**

We recommend using a high-quality, high-strength white PVA wallcovering glue. The glue must be applied directly to the wall and not excessively; it must not be diluted with solvents or any other type of liquid.

Important: follow the instructions of the glue manufacturer. Texam declines any kind of responsibility regarding the choice of the adhesive.

**2. WALL PREPARATION:**

Before starting to install your product, make sure that the wall is: flat, clean, perfectly dry in depth, compact, slightly absorbent, uniform color, solid, free of grease, dust, plaster, oil or pencil. Also be sure to remove previous wallcoverings and isolate or eliminate raised spots.

Any light-colored wallcovering requires a clear, uniform wall; if the color of the wall is significantly different from the color of the wallcovering it is advisable to first apply a primer on the wall which must be the same color as the wallcovering. It is also advisable to treat absorbent and dusty walls (such as plaster ones).

**3. INSTALLATION:**

Hang the sheets side by side following the roll number sequence, starting from the lowest number up to the highest; hang and finish one sheet at a time.

After hanging 3 sheets, check the result: if there are defects, stop working and contact us immediately.

Always handle the material with care and avoid bending or damaging it. Apply the glue evenly; use the brush near the ceiling, skirting board, corners and for all remaining parts use a microfiber roller. Flatten the joints with a rubber roller, taking care not to let the glue come out; if this happens, clean promptly with a clean sponge moistened with warm water or with a clean, damp, lint-free white cloth; use only clean water and no soap, taking care not to rub the substrate excessively (TEXAM cannot be held responsible in case of damage to the product during the cleaning process). Gently pass a plastic spatula on the wallcovering to eliminate any air bubbles. Cut off excess material using a Stanley knife.

**SPECIAL WARNINGS:**

It is recommended for this product to change the cutting blade often. It is possible to find a slight color difference to the original sample (due to the craftsmanship of production) and to find small impurities in the quartz.

For this product is essential to use a high strength glue for heavy wallpapers.

This wallcovering needs to be moistened on the back with a sponge, leaving it to rest for 10 minutes before applying it, to ensure greater elasticity during installation. Finally, we recommend, once all the product has been hanged, to pass a clean brush over the entire surface in order to remove excess quartz.

**ATTENTION:**

Any complaints must be made within 10 days of receipt of the material, with a copy of the invoice, photographs of the defect and returning the material itself.

Complaints beyond the hanging of 3 sheets will not be accepted. If the claim is justified, Texam's liability is limited regarding the free replacement of the material. The cost of the labour will not be reimbursed under any circumstances.

For any further information please visit our site [texamhome.com](http://texamhome.com)



Light Resistance  
Good lightfastness



Breathable



How to remove  
Strippable



Adhesive  
Apply an adhesive for non woven wallcovering directly to the wall



Washability  
Spongeable



Fire resistant  
On request

TEXAM  
WALL MASTERS

Via Milano 10, 24030, Presezzo (BG) ITALIA

TEL: +39 035 460449 [www.texamhome.com](http://www.texamhome.com)

