

www.texam-wallmasters.com

T+39 035 460449 | [info@texamhome.com](mailto:info@texamhome.com)  
| Via Milano 10, 24030 Presezzo (BG) Italy

Collection  
**STONE**

HANGING INSTRUCTIONS

---

**WARNING: DO NOT INSTALL THE PRODUCT BEFORE CAREFULLY READING THE INSTRUCTIONS**

Thank you for choosing Texam Wall Masters' Italian artisan creations. For optimal and professional results, we recommend consulting a professional installer.

**GENERAL INFORMATION:**

Before installing the product, check that the color, pattern, quantity, and quality match the item ordered; also ensure that you have received products from the same production batch. If any defects are found, the purchased material must be returned in full and in its original packaging; claims will not be accepted for cut or glued products. Variations in color and texture are inherent to the handcrafted manufacturing process. We recommend removing the product from its packaging 24 hours before installation and leaving it in the environment where it will be installed, so that temperature and humidity adjust to the product and prevent shrinkage during installation.

**INSTALLATION:**

**1. ADHESIVE:**

We recommend using a high-quality, strong-hold PVA wallpaper adhesive. The adhesive should be applied directly to the wall in a moderate amount; it should not be diluted with solvents or any other liquid. Important: follow the adhesive manufacturer's instructions. Texam declines any responsibility regarding the choice of adhesive.

**2. WALL PREPARATION:**

Before starting the installation, ensure the wall is smooth, clean, completely dry, solid, slightly absorbent, uniformly colored, and free of grease, dust, plaster, oil, or pencil marks. Remove previous wall coverings and address any protruding points. Highly absorbent or dusty walls (e.g., plaster) should be treated with a primer.

**3. INSTALLATION:**

Install the panels side by side following the roll's numerical sequence, from the lowest to the highest number; install and finish one panel at a time. After installing three panels, check the result; if defects are observed, stop work immediately and contact the manufacturer. Handle the material carefully to avoid bending or damaging it. Apply the adhesive evenly; use a brush near the ceiling, skirting boards, and corners, and a microfiber roller for the remaining areas. Smooth the seams with a rubber roller, taking care not to squeeze out the adhesive; if this occurs, promptly clean with a clean sponge dampened with warm water or a clean, lint-free, damp cloth; use only clean water, no detergent, and avoid excessive rubbing. Texam cannot be held responsible for damage occurring during cleaning. Use a wallpaper roller to remove any air bubbles. Trim excess material using a spatula as a guide and a sharp blade.

**SPECIFIC INSTRUCTIONS:**

For this product, frequently changing the cutting blade is recommended. Slight color variations from the original sample may occur due to the handcrafted nature, and small quartz impurities may be present. A high-strength adhesive for heavy wallpapers is essential. This wall covering should be moistened on the back with a sponge and left to rest for 10 minutes before application to ensure greater flexibility during installation.

**WARNING:**

Any claims must be made within 10 days of receiving the material, including a copy of the invoice, photographs of the defect, and return of the material. Claims will not be accepted after more than three panels have been installed. If the claim is justified, Texam's responsibility is limited to free replacement of the material. Labor costs will not be reimbursed.

For further information, visit our website [texam-wallmasters.com](http://texam-wallmasters.com).