

TEXAM

T+39 035 460449 F+39 035 461452 | info@ texamhome.com | Via Milano 10, 24030 Presezzo (BG) Italy | V AT I T 0 0 9 1 6 3 7 0 1 6 6

www.texamhome.com

Collection

# MYSTIC FOREST

HANGING INSTRUCTIONS

### WARNING: DO NOT INSTALL THE PRODUCT BEFORE YOU HAVE READ THE INSTRUCTIONS CAREFULLY.

Thank you for choosing Texam Wall Masters Italian handcrafted creations. For an optimal and professional result we recommend contacting a professional installer.

#### GENERAL INFORMATION

Before installing the product, check that the color, design, quantity and quality are those ordered; also make sure that you have received the same production batch. Should there be errors of this kind, we ask you to return the complete order to us in the original packaging; we will not accept any claims of the cut or glued product. Any variations in color and texture depend on the artisan manufacturing technique. We recommend removing the product from the packaging 24 hours before installation and leaving it in the room where it will be installed so that it adapts to the temperature and humidity of the room, to prevent the product from shrinking.

#### WALL COVERING INSTALLATION

#### 1 GIUE

We recommend using a high-quality, high-strength white PVA wallcovering glue. The glue must be applied directly to the wall and not excessively; it must not be diluted with solvents or any other type of liquid.

Important: follow the instructions of the glue manufacturer. Texam declines any kind of responsibility regarding the choice of the glue.

### 2. WALL PREPARATION:

Before starting to install the product, make sure that the wall is: flat, clean, perfectly dry in depth, compact, slightly absorbent, uniform color, solid, free of grease, dust, plaster, oil or pencil. Also be sure to remove previous wallcoverings and isolate or eliminate raised spots.

Any light-colored wallcovering requires a clear, uniform wall; if the color of the wall is noticeably different from the color of the wallcovering, it is advisable to match it as much as possible to the color of the wallpaper. It is also advisable to treat too absorbent and dusty walls (such as plaster walls) with a special primer.

## 3. INSTALLATION:

Hang the lengths of wallcovering side by side following the roll number sequence, starting from the lowest number up to

the highest; hang and finish one sheet at a time.

After hanging 3 sheets, check the result: if there are defects, stop working and contact us immediately.

Always handle the material with care and avoid bending or damaging it.

Apply the glue evenly, use the brush near the ceiling, skirting board, corners and for all remaining parts use a microfiber roller. Flatten the joints with a rubber roller, taking care not to let the glue come out; if this happens, clean promptly with a clean sponge moistened with warm water or with a clean, damp, lint-free white cloth; use only clean water and no soap, taking care not to rub the substrate excessively (TEXAM cannot be held responsible in case of damage to the product during the cleaning process). Gently pass a soft rubber pressure roller on the wallcovering to eliminate any air bubbles. Cut off excess material using a Stanley knife.

# SPECIAL WARNINGS:

It is possible to find a slight color difference with the original sample (due to the craftsmanship of the production). Use the soft rubber pressure roller on the wallcovering in a gentle and delicate way.

## ATTENTION

Any complaints must be made within 10 days of receipt of the material, with a copy of the invoice, photographs of the defect and returning the material itself.

Complaints beyond the hanging of 3 sheets will not be accepted. If the claim is justified, Texam's liability is limited regarding the free replacement of the material. The cost of the labour will not be reimbursed under any circumstances.

For any further information please visit our site texamhome.com







How to remove Strippable



Breathable



Fire resistant



Washability

REVERSE HANG ONLY IF SPECIFIED ON THE INDIVIDUAL ROLL'S LABEL